



Parental Controls

It's Simple As
1 2 3

Quick Start Guide:

- 1 Press the **MENU** button and navigate to and select the **Settings** category.
- 2 Navigate to the Parental Controls card and select it by pressing **OK**.
- 3 Choose **settings** and you will be taken to the Parental Controls menu.

Standard Elevate Parental Controls FAQs:

Which programs can I lock?

There are robust Parental Controls, including the ability to lock shows by TV Rating, Movie Rating, and Channel. In addition, you can lock out individual shows, including recorded programs. The system also records scheduled shows that are blocked by parental controls. For more detailed instructions, see **Parental Controls** in the Elevate User Guide or view video tutorials at hbc.com/support/elevate.

How can I access locked programs?

You'll need to enter your PIN. The first time you use Parental Controls, the system asks you to create a PIN. You are able to change your PIN later. For more detailed instructions, see **Working with your PIN** in the Elevate User Guide or view video tutorials at hbc.com/support/elevate.

Can I lock and unlock programs?

Yes; you can lock and unlock your shows by TV Rating, Movie Rating, and Channel. You can also turn off all your Parental Controls at the same time or unlock a show for a specified amount of time. For more detailed instructions, see **Locking and Unlocking Programs** in the Elevate User Guide or view video tutorials at hbc.com/support/elevate.

What if I forget my PIN?

Contact Wizards Technical Support at **(877) 457-9669** if you are unable to recall your PIN and they can help you with resetting it. For more detailed instructions on your PIN, see **Working with your PIN** in the Elevate User Guide or view video tutorials at hbc.com/support/elevate.

Will these Parental Control Settings apply to Elevate VOD?

No; these settings only apply to Elevate TV. If you're looking for information on how to set up Parental Controls and a PIN for Elevate VOD, see the **Standard Elevate VOD FAQs**, the **On Demand** section in the Elevate User Guide, or view video tutorials at hbc.com/support/elevate.

View Elevate video tutorials and more instructions at hbc.com/support/elevate

Need help? Visit our support page at www.hbc.com/support or contact Wizards Technical Support at (877) 457-9669.

